

Ankle Brachial Index

Name	Date
------	------

The Ankle-Brachial Index (ABI) is a simple and non-invasive diagnostic test used to assess the blood flow in the arteries of the legs and arms. It compares the blood pressure measurements taken at the ankle and the arm to determine if there is any narrowing or blockage in the arteries supplying blood to the legs.

Instructions

1. Get the equipment ready. You'll need a blood pressure cuff, a Doppler ultrasound device (or an automated device with Doppler capabilities), and a stethoscope.
2. Have the patient lie down comfortably on an examination table. Make sure they're relaxed and at ease.
3. Begin by placing a blood pressure cuff around the patient's upper arm. Make sure it's snug but not too tight.
4. Locate the brachial artery, which is on the inside of the upper arm.
5. Apply the Doppler device or stethoscope over the artery, and inflate the cuff until you can no longer hear the pulse.
6. Slowly deflate the cuff while listening for the return of the pulse. Note the systolic blood pressure reading when the pulse first becomes audible. This is your brachial pressure.
7. Now, it's time to move on to the ankles. Place a blood pressure cuff around the patient's ankle, just above the bony prominence.
8. Again, make sure it's snug but not uncomfortably tight.
9. Locate the dorsalis pedis artery or the posterior tibial artery on the patient's foot. Apply the Doppler device or stethoscope over the artery.
10. Inflate the cuff around the ankle until the pulse disappears. This ensures accurate measurements.
11. Slowly deflate the cuff while listening for the return of the pulse. Note the systolic pressure reading when the pulse first becomes audible. This is your ankle pressure.
12. Finally, calculate the Ankle-Brachial Index. Divide the higher ankle pressure by the higher brachial pressure to get the ratio.

Interpreting the results

The ABI provides a ratio that helps determine the presence and severity of peripheral artery disease (PAD). Here's how to interpret the results:

- **Normal ABI:** A normal ABI is typically between 1.00 and 1.40. This suggests that blood flow in the legs is normal, without significant narrowing or blockage in the arteries.
- **Abnormal ABI:** An ABI value of 0.90 to 0.99 indicate reduced blood flow and suggests the presence of peripheral artery disease (PAD). The lower the ABI, the more severe the blockage or narrowing may be.

- **Severe ABI:** In some cases, an ABI value of less than 0.90 can indicate non-compressible or rigid arteries due to calcification. This can make accurate measurements challenging and may require further assessment or alternative diagnostic methods.

Reminders

- Make sure the patient is relaxed and comfortable throughout the test.
- Take measurements on both sides of the body (left and right) to compare results.
- If the patient has any wounds or infections on their legs or feet, avoid placing the cuffs over those areas.
- Ensure proper positioning of the Doppler device or stethoscope to accurately capture the blood flow sounds.
- If the patient experiences any discomfort during the test, stop immediately and address their concerns.

Additional notes